

SUPER PRO PATCH KIT



Super Stone® Super PRO Patch Kit is a ready-to-use knock down finish repair application.

RECOMMENDED USAGE

- | | |
|--|--|
| <ul style="list-style-type: none">• Repairing Concrete Overlay• Shallow Repairs, less than ¼"• Floors, Walls & Ceilings• Sidewalks, Driveways, Pool Decks,• Stucco and Wall/Ceiling Repair• Patching Divot Holes left by carpet tacks | <ul style="list-style-type: none">• Exceptional Bonding• Fast Set Time• Easy to Mix• Tintable• Durable for High Traffic Areas• Cures to 5,500 psi |
|--|--|

COVERAGE

1 Kit Covers Approximately 8-12 ft² at 1/16" thick

DRY TIME

Dry time varies based on temperature and humidity. Do not wet for 24 hours.

SURFACE PREPARATION

Remove all loose deck material to reveal area to be patched. Grind edges of existing decking so that the area to be patched and the existing material create a smooth transition. Wet a tile sponge and wipe away dust and debris from the patch area. Do not soak the area, only use enough moisture to clean the area. All repaired areas MUST be free of dust or debris before Super Stone® Super PRO Patch Kit is applied.

APPLICATION

Mixing Instructions

Smooth or textured finish: Mix thoroughly with 16 oz of water and 4 lbs of mix.

Knock down finish: Use less water. Start with 12 oz and add an ounce at a time until the desired consistency is obtained.

Mix no more than 16 oz of water per kit. Dry times vary dependent upon temperature, humidity, and mixing water temperature. After application protect from freezing and moisture water for at least 24 hours. Air and surface temperature of the substrate will affect the working time and method of curing needed.

Once Mixed

Only mix material needed and apply mixture to cleaned patch area with a margin trowel or spackle knife at 1/16" thickness. Let the material set for approximately 5 minutes depending upon the temperature. Cooler temperatures will take longer to set. Warm or hot temperatures will set quicker. Dip the tile sponge into the bucket of cool water and wring out so that the sponge is moist but not soaked. Use the sponge to blend the edges and smooth the first coat. Mix the remainder of the patch

kit. Dip a long-bristled paint brush into the patch kit and flick the material onto the patch area. Wait about 5 minutes' and use a pool trowel to knock down the drops of material flicked from the brush. One pass is all that is needed. The area should be completely dried within a few hours. Use the edge of the trowel to scrape any nips or burs from the patched area. A grinding stone may also be used. The deck is now ready to be resealed once it is fully cleaned and dried.

SAFETY PRECAUTIONS

Avoid contact with eyes, skin, and clothing. First Aid: **Eyes**-- In case of eye contact flush right away. **Ingestion**-- rinse mouth thoroughly with water. Do not induce vomiting. **Skin**-- Immediately flush contaminated areas with lukewarm, gently running water. **Inhalation**-- If you experience difficulty breathing, remove yourself from the area to obtain fresh air. If symptoms persist or develop, seek medical attention.

Limited Warranty: *Since no control is exercised over product use, Super Stone® only warrants that this product is of consistent quality within manufacturing tolerances. Seller's and manufacturer's obligation under this warranty shall be limited to refunding the purchase price of the portion of the material proved to be defective. NO OTHER ORAL OR WRITTEN REPRESENTATION OR STATEMENT OF ANY KIND, EXPRESSED OR IMPLIED, NOW OR HEREAFTER MADE IS AUTHORIZED OR WARRANTED BY SUPER STONE, INCLUDING THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Super Stone will not be liable for special, incidental or consequential damages, including for delays or lost profits.*

For Professional Use

DANGER!

CAUSES SKIN IRRITATION, ALLERGIC SKIN REACTION, SERIOUS EYE DAMAGE, RESPIRATORY IRRITATION, CANCER, AND DAMAGE TO ORGANS THROUGH PROLONGED OR REPEATED USE. KEEP OUT OF THE REACH OF CHILDREN.

