

# FROG JUICE™



Super Stone® Frog Juice is a polymer modified water proofing additive designed to water proof concrete surfaces where there is foot traffic only such as basements, balconies, patios, decks, walkways, interior floors, shower pans, etc. Frog Juice is specifically formulated to be used with Super Stone® Wet & Ready Gray. It is light green in color and will stop hydrostatic pressure. This product meets and surpasses ASTM C1306.

## RECOMMENDED USAGE

- Super Stone® Wet & Ready Gray
- Masonry Surfaces
- Indoor and Outdoor Use

## ADVANTAGES

- Stops Hydrostatic Pressure
- Water Proofing Agent

## COVERAGE

1 Gallon Covers Approximately 200 ft<sup>2</sup> at 1/8"

## DRY TIME

24 hours for foot traffic

## SURFACE PREPARATION

Before applying Super Stone® Frog Juice, make sure all contaminants and bond-inhibiting materials are removed from the surface. All coatings must be down to the raw concrete. Use Super Stone® Cleaner/ Degreaser to remove dirt, oil, and other petroleum based contaminants. Pressure clean the surface and acid wash. Neutralize the surface after acid washing with 1 pint of ammonia mixed with 5 gallons of water.

## APPLICATION

Spray a light mist of water to dampen the surface so that the concrete doesn't absorb the moisture out of the Wet & Ready. If your concrete is superabsorbent, it is recommended to prime the day before with Super Stone® Polymer by mixing 1 part water to 1 part polymer and applying. Two gallons of this mix will cover approximately 400 ft<sup>2</sup>. Apply with a squeegee. The primed surface will remain tacky the next day.

**Now your floors are ready to be water proofed.**

Mix 1 gallon of Frog Juice with 3 quarts of water, then pour into a 5-gallon bucket. Add one 50lb. bag of Super Stone® Wet & Ready Gray and mechanically mix with a mud mixer. Let sit for 5 minutes. Remix and you can add up to 1 quart of water at this time if needed. Apply with a squeegee at no more than 1/8" thick. Do not add more water as this will weaken the integrity of the product. All materials must be kept in the shade. Do not use steel cleats. Do not apply in temperatures below 50 degrees or above 90 degrees. Let dry for 24 hours.

## Now your floor is ready for the finishing coat.

You may apply Super Stone® Super Tex Wet & Ready, Super Surface, Wood Linoleum, etc. over the application.

## SAFETY PRECAUTIONS

In case of fire, use water spray, foam, dry powder, Carbon Dioxide. Avoid contact with eyes, skin, and clothing. First Aid: **Eyes**-- In case of eye contact flush right away with large amounts of water for at least 15 minutes and seek immediate medical attention. **Skin**-- Wash the affected area thoroughly with soap and water. **Inhalation**-- If you experience difficulty breathing, remove yourself from the area to obtain fresh air. If symptoms persist or develop, seek medical attention. **Ingestion**-- Do not induce vomiting. Never give anything by mouth to an unconscious or convulsing person. Rinse out the mouth with water. Get medical attention immediately.

**Limited Warranty:** *Since no control is exercised over product use, Super Stone® only warrants that this product is of consistent quality within manufacturing tolerances. Seller's and manufacturer's obligation under this warranty shall be limited to refunding the purchase price of the portion of the material proved to be defective.* NO OTHER ORAL OR WRITTEN REPRESENTATION OR STATEMENT OF ANY KIND, EXPRESSED OR IMPLIED, NOW OR HEREAFTER MADE IS AUTHORIZED OR WARRANTED BY SUPER STONE, INCLUDING THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Super Stone will not be liable for special, incidental or consequential damages, including for delays or lost profits.

FOR PROFESSIONAL USE

**WARNING!** INGESTION MAY CAUSE GASTROINTESTINAL DISTURBANCES. KEEP OUT OF THE REACH OF CHILDREN.

